



Použití náhradních nožů NOGA

		hliník	měď	mosaz	litina	ocel	nerez	plast	sklo
Nože typu N pro: TB1000, LB1000	BN1010 N1	●	●	●		●	□	●	
	BN1011 N1L	●	●	●		●	□	●	
	BN1015 N1C	●	●	●		●	●	□	
	BN1012 N1Tin	●	●	●		●	●	●	
	BN2010 N2	●	●	●	●	●	□	●	
	BN2015 N2C	●	●	●	●	●	●	□	
	BN1014 N1D							●	●
	BN3010 N3	●	●	●	□	●	□	●	
	BN6010 N6	□	□	●		●	□	□	
Nože typu S pro: RB1000, LB1000, NB1000-NB500	BS1010 S10	●	●	●		●	□	●	
	BS1011 S10LH	●	●	●		●	□	●	
	BS1012 S10Tin	●	●	●		●	●	●	
	BS1016 S10C	●	●	●		●	●	□	
	BS2010 S20	●	●	●	●	●	□	●	
	BS2015 S20C	●	●	●	●	●	●	□	
	BS3010 S30	●	●	●	□	●	□	●	
	BS3510 S35	●	●	●	●	●		●	
	BS1018 S100	□	□	●		●	●	□	
	BS1014 S1D							●	●
	BK1010 S101	●	●	●	□	●	●	●	
	BK1011 S101Lh	●	●	●	□	●	●	●	
	BK1012 S101Tin	●	●	●		●	●	●	
	BK3000 S150	●	●	●		●	●	●	
	BK2010 S202	●	●	●	●	●	□	●	
	BS6010 S60	□	□	●		●	□	□	
	BC1010 TC	●	●	●		●	□	●	
	BO1010 OR	●	●	●		●	□	□	
EX2000 RDE18	●	●	●		●	□	●		
nože pro: SC1000, MS1000, I S1000, SC8000	BD5010 D50	●	●	●		●	□	●	
	BD5510 D55	●	●	●		●	●	□	
	BD6610 D66	●	●	●		●	□	●	
	BD7510 D75	●	●	●		●	□	●	
	BD7710 D77	●	●	●		●	□	●	
	BT8010 T80	●	●	●		●	□	●	
	BT1210 T120	●	●	●		●	□	●	
nože pro: DB1000, KW1000, RC1000, R C2000	BN8010 N80	●	●	●		●	□	□	
	BN8043 N80M42	●	●	●		●	●	□	
	BN7010 N70K	●	●	●		●	□	□	
	BN8110 N80K	●	●	●		●	□	□	
	BN8143 N80KM42	●	●	●		●	●	□	
	BN9010 N90K	●	●	●		●	□	□	
	BR1010 R1	●	●	●		●	□	●	
	BR2010 R2	●	●	●		●	□	●	
nože pro: LH1000, NC100 0-NC4000	BL1010 L1	●	●	●		●	□	●	
	BL3010 L3	●	●	●		●	□	●	
	BL4010 L4	●	●	●		●	□	●	
	BL5010 L5	●	●	●		●	□	●	
	BL6010 L6	●	●	●		●	□	●	
	BL7010 L7	●	●	●		●	□	●	

Ceny jsou uvedeny bez DPH

Vhodný



použitelný



nevhodný